LEADER IN INDUSTRIAL TOOLS & EQUIPMENT

# Technical sheet

| | |
|---|---|
| Image not found or type unknown | **WHEEL NUT cover indicator HBL**<br>Marque:<br>Ref Product: wire:HBL<br>Ref Mcmining: WHEELNUT------ |

| | DESCRIPTIONS | |
|---|---|---|
| WHEEL NUT cover indicator HBL<br>goujons rétroréfléchissant<br>Wheel Nut indicator<br>- Is a loose wheel nut indicator that is used extensively by the Transport industry as an enhancement and Development of fleet safety roadworthiness procedures, daily Walk-round inspection and defect reporting and scheduled maintenance requirements.<br>- allows accurate monitoring for Loose wheel nuts<br>- helps prevent wheel hub damage or the loss of a road wheel should a wheel nut loosen.<br><br>heat sensitivity :<br>when higher than normal operational temperature are reached, the Wheel Check Indicator is designed to melt indicating an imminent Bearing failure or braking issues.<br>The Wheel Check Indicator is fixed to the wheel nut by gripping the six corners of the hexagon of the wheel nut. When the wheel is being fitted out the Wheel Check Indicator pointers should be aligned and set in a recognizable pattern. Should a wheel nut loosen off, the Wheel Check Indicator has no option but to move with the nut and so break the recognizable pattern that was set, thus indicating the wheel nut has begun to rotate and therefore to loosen.<br><br>Color: Yellow<br>Material:PP<br>Melting point: 165ºC | | |
| **References** | **REF MC MINING** | **Fitment** |
| HBL19 | **WHEELNUT19MM-Y** | for 19mm |
| HBL21 | **WHEELNUT21MM-Y** | for 21mm |
| HBL22 | **WHEELNUT22MM-Y** | for 22mm |
| HBL24 | **WHEELNUT24MM-Y** | for 24mm |
| HBL30 | **WHEELNUT30MM-Y** | for 30mm |
| HBL32 | **WHEELNUT32MM-Y** | for 32mm |
| HBL33 | **WHEELNUT33MM-Y** | for 33mm |
| HBL34 | **WHEELNUT34MM-Y** | for 34mm |
| HBL36 | **WHEELNUT36MM-Y** | for 36mm |
| HBL41 | **WHEELNUT41MM-Y** | for 41mm |